


How to set up a Capture Advance NVR/DVR to record continuously with motion detection

Follow the steps below outlining how to set a Capture Advance NVR or DVR to record continuously with motion detection.

Important Note: Capture Advance NVRs and DVRs are configured to record continuously by default.


Procedure:

1. Log in to the Capture Advance NVR/DVR.
2. Go to [Settings](#) > [Record](#) > [Record Schedule](#). Select the channel and make sure that [Enable Record](#) is turned on.
3. You can also copy the setting to other channels by clicking [Copy](#) > [select the channels](#) > [OK](#). Click [Apply](#) to complete the process.
4. Go to [Alarm](#) > [General](#). Make sure that [Enable Alarm](#) is on.




5. Go to [Motion Detection](#) > select the channel and turn on [Enable Motion Detection](#).

- Under **Event Actions**, make sure to turn on **Enable Event Recording** and select the corresponding channel under **Recording Channel**. Click **Apply** to save the setting.




- You can also copy the setting to other channels by clicking **Copy** > select the channels > **OK**. Click **Apply** to complete the process.

- Go to the **Detection Area** tab. Draw the detection area and set the **Sensitivity**. Area with red grid means selected. Click **Apply** to save the setting.



9. You can also **copy the setting to other channels** by clicking **Copy** > select the channels > **OK**. Click **Apply** to complete the process.
10. Go to the **Schedule** tab. Set your preferred schedule in the schedule block. Then, click **Apply**.



11. You can also **copy the setting to other channels** by clicking **Copy** > select the channels > **OK**. Click **Apply** to complete the process.